



USER MANUAL

P1571Y-C6

WWW.YENTEK.EU



Disclaimer

Except for the accessories attached to the product as specified herein, what is contained in this user manual does not represent the commitments of Yentek Europe GmbH and reserves the right to revise this User Manual, without prior notice, and will not be held liable for any direct, indirect, intended or unintended losses and/or hidden dangers due to installation or improper operation.

Before ordering the products, please learn about the product performance from the distributors to see if it is in line with your needs. The ownership of other trademarks involved in this manual is owned by its respective owners.

The contents of this manual are protected by copyright law. All rights are strictly reserved. Any form of unauthorized reproduction including but not limited to carbon copy, facsimile transmission and electronic copy or email is prohibited.

For more information, please visit:

Website: <http://www.hanzsung.com>

Support: fawang.luo@hansung.com

3.2.13 Boot

3.2.14 Security

3.2.15 Save&Exit

Appendix

Appendix one: Glossary of terms

Appendix Two: Common issue analysis and solution

Chapter 1 Product Introduction

1.1 Product Photo:



Image 1: P1571Y-C6 Front View



Image 2: P1571Y-C6 Lateral I/O View



Image 3: P1571Y-C6 Bottom I/O View

1.2 Dimension




Image 1: Lateral IO View





Image 2: Bottom IO View

1.3 Product Specification



P1571Y-C6 Dimension

1.4 Product Specification**➤ LCD Screen**

15" LCD, resolution 1024 * 768, 4: 3 screen, 350 cd/m²

➤ Touch Screen

Capacitive, support 10 point touch (can change to resistive touch screen)

➤ LAN

2*Intel I210 Gigabit Ethernet, support Wake On LAN

➤ Audio

1*Line out, 1*Mic

➤ COM Port

6*RS232, COM1~2 RS232 DB9, COM2 support RS485/422, COM3~6 RS232 on 2*15pin Phoenix connector, COM3 support RS485 selectable, COM1~2 support pin9 5V/12V charging function

➤ Expansion Slot

1*M.2/WiFi, support Key-E,2230, WiFi module

1*M.2/5G, support Key-B,2242/52,5Gi module

➤ Storage

1*2.5 SATA port

1*M.2/SSD, support Key M, 2280, NVME PCIe4 SSD

1*MSATA

➤ IO Port

1*Power button, 1*One-key recovery (reset key optional, default one-key recovery)

1*AC LOSS (auto power ON/OFF switch)

1*Power LED, 1*HDD LED

1*HDMI

2*Intel I210 Gigabit Ethernet, support Wake On LAN

4*USB3.0, 2*USB2.0

1*Mic, 1*Line out

6*RS232 COM port,COM1~2 RS232 DB9,COM2 support RS485/422,COM3~6 RS232 on 2*15P Phoenix connector,COM3 support RS485,COM1~2 support the 9th pin charged function(5V/12V);

10-digit DIP switch, for RS232/485/422 selection

1*DC_In Jack and 1*2pin Phoenix connector, support 9-36V wide voltage input

➤ **Cooling System**

Fanless design

➤ **Watchdog**

Support hardware reset function (256 levels, 0~255 seconds)

➤ **Power Connector**

1*DC and 1*2P Phoenix connector, support DC 9-36V wide voltage input

➤ **Chassis**

Dimension: 272mm x 214mm x 62mm (L*W*H)

Installation: VESA/ Embedded

➤ **Working Environment**

Operating Temp.: -10°C~50°C

Relative Humidity: 5~90% relative humidity, non-condensing

Storage Temp.: -20°C~60°C

1.5 Packing

➤ **Packing Size:** 495mm x 395mm x 158mm (L*W*H)

➤ **N.W:** 3.8KG

➤ **G.W:** 5.3KG

➤ **Accessory List:**

Name	Qty
Buckle	2pcs

1.6 Order Information**Order Information**

No.	Model	CPU	Memory	MSATA	HDMI	LAN	COM	USB	Power
1	P1571Y-C6 V1.0(J6412)	J6412/2.0G	2*SODDDR4	1	1	2	6	6	9-36V
2	P1571Y-C6 V1.0(7300U)	I5-7300U/2.6G	2*SODDDR4	1	1	2	6	6	9-36V
2	P1571Y-C6 V1.0(8260U)	I5-8260U/1.6G	2*SODDDR4	1	1	2	6	6	9-36V
2	P1571Y-C6 V1.0(10210U)	I5-10210U/1.6G	2*SODDDR4	1	1	2	6	6	9-36V
2	P1571Y-C6 V1.0(1135G7)	I5-1135G7/2.4G	2*SODDDR4	1	1	2	6	6	9-36V


Above order information just for reference

Chapter 2 Operation Guide

2.1 Installation Steps

2.1.1 Display (HDMI)

The computer provides 1*HDMI port



HDMI signal definition

Pin	Signal Name	Pin	Signal Name
1	TMDS Data2+	2	TMDS Data2 Shield
3	TMDS Data2-	4	TMDS Data1+
5	TMDS Data1 Shield	6	TMDS Data1-
7	TMDS Data0+	8	TMDS Data0 Shield
9	TMDS Data0-	10	TMDS Clock+
11	TMDS Clock Shield	12	TMDS Clock-
13	CEC	14	HRC Data-
15	SCL	16	SDA
17	GND	18	+5V
19	Hot Plug Detect		

2.1.2 Network (LAN1-2)

2*Intel I210 Gigabit Ethernet

Network LED Definition

Active/Link LED		SPEED LED	
State	Description	State	Description
Off	No Link	Off	10Mbps Connection
Blinking	Data Activity	Orange	100Mbps Connection
On	Link	Green	1Gbps Connection

2.1.3 Audio (Line-out/Mic)


1*Line-out and 1*MIC port

2.1.4 Power Button (POWER)

1* Power button [PWR], 1*Reset button [RST], 1*Power LED [PWRLED], 1*HDD LED

2.1.5 COM Port (COM1-2)

COM1 RS232 DB9 COM port, COM2 RS232/485/422 DB9 port,COM3~6 RS232/485 on 2*15pin Phoenix connector,COM1~2 support the 9th pin charged function, COM2 and COM3 RS232/485 switching via dip switches, COM3 RS422 is realized by a combination of dip switches and the COM2_SW1 jump cap on the board, DIP switch please refer to 2.1.7, COM3~6 definition please refer to 2*15P Phoenix connector.



(COM Port Image)

COM1 RS232 Signal Definition

Pin	Signal Name	Pin	Signal Name
1	DCD	2	RXD
3	TXD	4	DTR
5	GND	6	DSR
7	RTS	8	CTS
9	RI	10	NC


COM2 RS232/485/422 Signal Definition

Pin	Signal Name	Pin	Signal Name
1	DCD/RS485-	2	RXD/RS485+
3	TXD/RS422+	4	DTR/RS422-
5	GND	6	DSR
7	RTS	8	CTS
9	RI	10	NC

2.1.6 2*15P Phoenix Connector (4*GPIO/4*COM)

The board provide a 2*15p Phoenix connector, 4-in 4-out GPIO, 4*COM, power

button.




2*15p Phoenix Connector

2*15P Phoenix Connector Definition


Pin	Signal Name	Pin	Signal Name
1	VCC	2	GPIO-GND
3	DI1	4	DO1
5	DI2	6	DO2
7	DI3	8	DO3
9	DI4	10	DO4
11	COM3_TXD	12	COM4_TXD
13	COM3_RXD_485+	14	COM4_RXD
15	COM3_485-	16	NC
17	GND	18	GND
19	COM5_TXD	20	COM6_TXD
21	COM5_RXD	22	COM6_RXD
23	NC	24	NC
25	GND	26	GND
27	+3.3V	28	FP_SPSW
29	GND	30	GND

2.1.7 DIP Switch (10 digit)




10-digit DIP switch image

COM2 RS232/RS485/RS422 selection via 6-digit DIP switch + COM2_SW1 (COM2_SW1 on P1081-C6 I/O board) jumper, COM3 RS232/RS485 selection via 4-digit DIP switch.




(P1081-C6 Graphics)




COM2_SW1

COM2 RS232/485 COM2_SW Setting



COM2_SW1

COM2 RS422 COM2_SW Setting



10-digit DIP switch image

COM2 RS232/485/RS422 Setting

	A	B	C	D	E	F
RS232	1	0	1	0	1	0
RS485	0	1	0	1	0	1
RS422	0	1	0	1	1	1

Note:COM2 RS232/485/422 also need COM_SW1 jumper setting on

P1081-C6

COM2_SW1 (COM2 RS232/485/422) Setting

Function	COM2_SW1 Setting
RS232/485	Short connect 2-3 , 5-6, 8-9, 11-12 pin
RS422	Short connect 1-2, 4-5, 7-8, 10-11 pin

COM3 RS232/485 Setting

	G	H	I	J
RS232	1	0	0	1
RS485	0	1	1	0


GPIO Charging Function Setting

Function	GPIO_SW1 Setting
+12V	Short connect 2-3 , 5-6, 8-9, 11-12 pin
+5V	Short connect 1-2, 4-5, 7-8, 10-11 pin



GPIO_SW1

GPIO 5V Setting




GPIO_SW1

GPIO 12V Setting

2.1.8 Power (9-36V)

Provide 1*DC adaptor port and 1*2pin Phoenix connector, support 9-36V input




1*2pin Phoenix Connector Definition

Pin	Signal Name	Pin	Signal Name
1	GND	2	VCC

2.1.9 Expansion Slot (M.2)

1* M.2/WiFi, support Key-E, 2230, WiFi module

1* M.2/5G, support Key-B, 2242/52, 5G module



Tips: . Please use a dedicated power adapter. 2. How to identify the alarm sound: (a long beep is system memory error; a short beep" is boot sound).